

Follow the steps below to update the Dynacom software.

- 1) Optional - Back-up historical data stored in the database with the existing Dynacom version by copying the .mdb file located in C:\Program Files\Dynamic Flow\your_application\ to another location for safekeeping.

For example, if you are running Micro MVL firmware, you would go to C:\Program Files\Dynamic Flow\MicroMVL and copy the MicroMVL.mdb file to another location.

- 2) Remove the existing Dynacom software from the computer, by using the Windows Control Panel. Select Uninstall a program, scroll down to locate the current version installed. Highlight the program and click on Uninstall. This will remove all of the program files and shortcuts from the computer.
- 3) When the uninstall is complete, download the new Dynacom application from our website: www.dynamicflowcomputers.com. Click the link for the new software version. A pop-up box will appear asking if you would like to Run or Save the file. Click 'Run' at the bottom of the pop-up box and follow the prompts to complete the set-up process.

For assistance with the installation, feel free to contact our office.