


1. Determine if the battery currently installed is rechargeable or non-rechargeable. The factory installed rechargeable battery is Sanyo #ML2016-HS1 and has a blue ring around the edge. The factory installed non-rechargeable battery is Sanyo #CR2450 and does not have a blue ring around the edge. If you have the non-rechargeable battery installed, please skip Step 2.

Figure A




2. If you have a rechargeable battery (Sanyo #ML2016-HS1) currently installed, and you are replacing it with a non-rechargeable battery (Sanyo #CR2450), please remove the component located at R15, as well as the diode connected to R15 (see Figure B below).

Figure B



Remove this component prior to installing a non-rechargeable battery



3. If the new battery is the same type as the currently installed battery, there is no need to remove any component. Simply desolder the old battery and install a new one.